

WALL MURAL INSTALLATION INSTRUCTION

PREPARATION

Step 1. Make sure the surface is smooth and clean.

Remove any old paint or murals that are coming off. Clean the surface with warm water and apply filler where necessary. If the surface is damaged, apply a primer coat or pre-paste before hanging murals. You should also prime the surface if it has bright colors as they could show

Step 2. Prepare the paste.

It was shipped to you with your order free of charge. Please read the instructions carefully before using.

HANGING

Step 1. Start by hanging them from left to right.

Before hanging, make sure none of the mural panels are missing and there are no defects or damage. Start by hanging them from left to right.

Make sure the panels are hung straight. It is vital that the first panel is hung straight. Draw vertical markings on the wall using a spirit level, a measuring tool and a pencil. Use markings as a guide to hang the first panel.

Step 2. Apply the paste directly on the mural.

Use a roller or a brush. It's important to cover the whole area with paste. After pasting mural leave it to soak for a period of 5-10 minutes. Hang the panels edge to edge. The panels should not overlap. Take care to press the panels together firmly at the seams. For the best result use a seam roller. Be careful to match up the pattern with the next panel and avoid getting wall mural paste on the front of the mural as this will show when it dries.

Note: Avoid harsh folds as this may cause cracks in the print.

Step 3. Smooth down the panels from ceiling to floor.

Use your hands or wall mural brush, starting from the middle and smoothing out towards the edges. Any small bubbles and folds will disappear once the mural has dried. If there are any spots of the paste on the front of the mural, use a damp cloth or sponge to remove them, but avoid rubbing.

